



# HEAT HERO

## INSTRUCTION MANUAL

Thank you for your purchase of Heat Hero™! This cordless ceramic heater provides simple and fast heat. Simply plug it in, set the temperature and enjoy the warmth. Stay comfortable with high and low setting! With ultimate control choose between 60-90F.

## IMPORTANT INSTRUCTIONS SAVE THESE INSTRUCTIONS

As with any electrical appliance, precautions need to be taken to minimize the risk of fire, electric shock, and injury to persons, including the following:

**Before plugging in Heat Hero™ please read through the entire instructions provided in this manual.**

## FOR IN-WALL USE ONLY

**CAUTION** - To reduce the risk of fire or electric shock connect directly to grounded three-prong wall outlet.

**WARNING :** To reduce the risk of fire or electric shock do not use with an extension cord.

**WARNING :** In order to avoid overheating, do not cover the heater.

**WARNING : POTENTIAL ELECTRICAL HAZARD  
NOT ADHERE TO.**

## IMPORTANT SAFETY INSTRUCTIONS

### Read all instructions before using this heater.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

-This heater must be plugged into a 120V, 15amp (or more) circuit of its own. Do not plug anything else into the same circuit. If unsure if your home meets this specification, consult a certified electrician prior to use. Risk of fire, overheating, malfunction, property damage, injury or even death may result if not adhered to!

- Connect to properly grounded, 3-prong outlet only. Do not connect the heater to extension cords, surge protectors, timers, direct breakers, or an outlet with other appliances connected to the same outlet. Risk of fire, overheating, malfunction, property damage, injury or even death may result if not adhered to!

-This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater.

-Keep combustible materials, such as furniture, pillow, bedding, paper, clothes, and curtains at least 3 ft. (0.9m) from the front of the heater and keep them away from the sides and rear of the heater.

-Extreme caution is necessary when any heater is used by or near

children, invalids, pets, or when the heater is left operating unattended.

-Always unplug the heater when not in use.

-Do not operate any heater with a damaged plug or after the heater malfunctions, has been dropped, or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.

- Do not use outdoors. Exposure to outdoor elements such as rain, snow, sun, wind, or extreme temperatures may cause the heater to become safety hazard.

-This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. This heater is not intended for use in any location that use GFCI outlets.

- Never place the heater where it may fall into bathtub or other water receptacles.

-To disconnect the heater, first turn the power button to the OFF position and then remove from the wall outlet.

-Do not allow foreign objects to enter or block any ventilation or

exhaust opening as this may cause electric shock, fire, or damage the heater.

- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surface, like a bed, where openings may become blocked.


- Allow at least 3 feet of unobstructed space to the front, rear or sides of the heater to allow for maximum heat, air, and ventilation flow.

- A heater has hot and arcing or sparking parts inside. Do not use heater in areas where gasoline, paint or flammable liquids are used or stored, nor use flammable solvents to clean the heater. Keep the heater dry at all times.


- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

**WARNING:** This heater has a voltage rating of 120 volts. It has a three blade, grounding-type plug. An adapter should not be used if a three-slot grounded receptacle is not available. **DO NOT DEFEAT THE SAFETY PURPOSE OF THE GROUND PLUG.**


## OPERATING INSTRUCTIONS




1. Plug Heat Hero™ into desired 120v power outlet. Use "Plug Rotation" for most convenient placement on wall.




2. Press "ON/OFF switch" on side of the unit to "ON" position to turn on the heater.



3. Select your desired temperature. Use the "+" button to raise temperature or "-" button to lower the temperature between 60-90 on "Digital Display."



4. Select you desired fan speed. Press "Fan Speed Button" to choose between High (HH) or Low (LL) on "Digital Display".



5. When finished, press "On/Off Switch" to "Off" position and unplug Heat Hero™ from power outlet. Store in a cool, dry place until next use.

## SETTING THE TIMER

Heat Hero™ has a built-in timer that will automatically turn the unit off after a set amount of time.

1. While Heat Hero™ is plugged in turned on, press the "Timer Button" to activate timer.
2. Repeatedly press "Timer Button" to set number of hours before Heat Hero™ turns off. You can choose between 1 - 12 hours.
3. Once desired hours have been chosen, stop pressing "Timer Button" to set.
4. To cancel timer, turn Heat Hero™ off.

**NOTE:** Heat Hero™ had automatic 12 hours default timer feature for safety reason.

## CARE AND MAINTENANCE

**WARNING:** Before beginning any maintenance, unplug your Heat Hero™, and allow to cool completely.

To clean, wipe the exterior with a non-abrasive, damp cloth. Use a mild soap if needed. Dry with a soft cloth.

## CAUTION: DO NOT LET LIQUID ENTER THE HEATER

**DO NOT** use alcohol, gasoline, abrasive powders, furniture polish, or rough brushes to clean the heater. This may cause damage to the casing of the heater.

**DO NOT** immerse Heat Hero™ in water.

Wait until the unit is completely dry before use. Store unit in a cool dry place when not in use.

## SPECIFICATION:

Voltage Rating 220-240 V~ 50-60 Hz  
Power Consumption 370 W at 25°C

## NOTICE

If the unit stops working due to over heat. Please detach unit from AC power and plug in again for reset.



You can help protect the environment!  
Please remember to respect the local regulations: hand in any non-working electrical equipment to an appropriate waste disposal centre.

Heat Hero™  
Made in China

